


SHAD

DUCATI MULTISTRADA 1200 V4 / V4 S / V4 S SPORT '21

TOP MASTER DOMV11ST



1 262773 x1



2 260648 x4
Ø16 Ø9 x 5



3 303017 x4
Ø6



4 304052 x4
M6 x 20 Din 7380

! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté.

